



BOSTIK

GLU DOTS

REMOVABLE ADHESIVE DOTS

DESCRIPTION

Bostik Glu Dots Removable are individually formed translucent dots of pressure sensitive adhesive, which are removable. Bostik Glu Dots Removable are safe, simple to use, acid and lignin free, and non-yellowing.

FEATURES AND BENEFITS

- Instant bond
- Double sided
- Acid and lignin free

RECOMMENDED USES

- Bostik Glu Dots Removable are ideal for arts & craft, scrap booking, card marking, collages and model making.
- Bostik Glu Dots Removable are the perfect size to allow for precise and accurate placing of small objects such as sequins, beads, rhinestones, wiggly eyes and many other craft embellishments.
- Bostik Glu Dots Removable stick to almost anything, including paper, wood, plastic, metal and glass.

SURFACE PREPARATION

1. Ensure surfaces are clean; dry free from grease and loose materials.
2. For best results, surfaces and surroundings should be pleasantly warm.
3. Take out a sheet of dots from the wallet.
4. Fold and then tear off, along the perforations, to remove as many dots as required.

APPLICATION

1. Peel off the printed release paper to reveal a Glu Dot left on the clear backing. The Glu Dot is now ready for use.
2. Press the Glu Dot firmly onto the item to be bonded and then slowly and carefully peel off the clear backing.
3. The Glu Dot will be adhered to the item, which can now be bonded to the other surface.



SPECIFICATIONS

Colour	Transparent
Form	Sticky adhesive dots
Composition	Hydrocarbon Polymer
Specific Gravity	1.0 approx
Pack Quantity	64 dots
Product codes: 64 dots	30800951

CLEAN UP

Carefully and very slowly peel away. As the adhesive gets stronger with time, it is recommended that the dots are removed by carefully rubbing and rolling them off the surface.

SHELF LIFE

24 months, unopened, from date of manufacture. Store in dry conditions between +5° C and +25° C

HEALTH AND SAFETY

This product is not classified as Dangerous Good or Hazardous Substance according to ADG Code and work safe Australia respectively. The product however, should be used in accordance with good occupational, health and safety practices. May cause irritation if swallowed, moderately irritating to eyes. Repeated or prolonged skin contact may lead to irritation. High concentrations of vapor may irritate respiratory tract. Release methyl ethyl ketoxime (MEK) until fully cured.

Do not swallow and avoid contact with skin as this may cause sensitization. If contact with eyes occurs, wash eyes with copious quantities of water and consult a doctor if irritation persists. For more details, refer Material Safety Data Sheet.

DISCLAIMER:

The information in this Technical Data Sheet is intended for the assistance of users and is of a general nature. It reflects the extent of our knowledge and experience of our products and is based on tests which we believe to be reliable. However, no guarantee of accuracy can be given due to the wide range of surfaces, environmental and field conditions and variations encountered in raw materials, manufacturing equipment and methods at the place where the work is performed. Some of these will be beyond our knowledge and control. Users are asked to make sure that the TDS in their possession is the latest issue. Likewise, we recommend users carry out their own tests to determine the suitability of the product for their particular purposes.

Any claim for a defective product must be filed within 30 days of discovery of a problem and must be submitted with written proof of purchase. Claims are not transferrable or assignable and extend only to the original purchaser/user. Bostik reserves the right to inspect alleged failure and no responsibility will be accepted unless Bostik is given the opportunity to do so. Bostik limits its liability to the replacement of the product/s proven faulty.

BOSTIK PHILIPPINES, INC.

35/F Raffles Corporate Center, F. Ortigas Jr. Road,
Ortigas Business Center, Pasig City 1600, Philippines
Tel No: +63 2 7900 5656 | Fax: +63 2 7900 5616

BOSTIK HOTLINE

Smart help +63 2 7900 5656

